





MATRIX mechatronics

High Performance Individual and Multi-Valves

www.bibus.uk



SOLENOID VALVES

Micro va Serie 320 Page		Function Voltage Flow rate Pressure range	2/2 • 3/2 6/12/24 VDC; Speed-Up! 30 l/min. 0-8 bar; Vacuum 10 ⁻⁵ Torr	Dimensions Weight	8 x 23 x 24.5 mm 9 g
Multi-va Series 58 Page 1	s D 10	Function Voltage Flow rate Pressure range	2/2 Speed-Up! 180 I/min. 0-5 bar	Dimensions Weight	28 x 100 x 49.6 mm 400 g
Individual Serie 720 Page 1	valve S D I4	Function Voltage Flow rate Pressure range	2/2 • 3/2 12 VDC; 24 VDC; Speed-Up! 50-100 I/min. 0-8 bar; Vacuum 10 ⁻⁵ Torr	Dimensions Weight	12 x 41 x 39.5 mm 35 g
Multi-va Serie 750 Page 1	s D 18	Function Voltage Flow rate Pressure range	2/2 • 3/2 • 3/3 • 5/2 12 VDC; 24 VDC; Speed-Up! 50-700 l/min. 0-8 bar; Vacuum 10 ⁻⁵ Torr	Dimensions Weight	55 x 55 x 48 mm 350 g
Individual Serie 820 Page 3	s D 30	Function Voltage Flow rate Pressure range	2/2 • 3/3 24 VDC; Speed-Up! 100-220 l/min. 0-8 bar	Dimensions Weight	12 x 37 x 28.5 mm 25 g
Individual	valve	Eurotion	0/0		
Series 820 ISD Page 3		Voltage Flow rate Pressure range	24 VDC 100-180 l/min. 2-8 bar	Dimensions Weight	12 x 37 x 53.5 mm 25 g
Multi-va Series 86 Page 3	s b 38	Function Voltage Flow rate Pressure range	2/2 Speed-Up! 1-750 l/min. 0-6 bar	Dimensions Weight	52 x 52 x 55 mm 450 g
Multi-va Series 880 Page 4	s D 42	Function Voltage Flow rate Pressure range	2/2 24 VDC; 24/5 VDC Speed-Up! 300-430 l/min. 0-8 bar	Dimensions Weight	12 x 75 x 41 mm 72 g
Multi-va Serie 89 Page 4	s D 46	Function Voltage Flow rate Pressure range	2/2 24 VDC; Speed-Up! 100-1620 l/min. 0-8 bar	Dimensions Weight	46 x 46 x 41.5 mm 160 g





ELECTRONIC PRESSURE REGULATORS

Pressure regulator Series EPR 100 Page 52	Regulating range Flow rate Input signal	0-7 bar 80 l/min. 0-5 V; 0-10 V; 4-20 mA; RS232 keypad	Dimensions Weight	118 x 70 x 40 mm 400 g
Pressure regulator Series EPR 200/300/500 Page 52	Regulating range Flow rate Input signal	0-7 bar max. 500 l/min. 0-5 V; 0-10 V; 4-20 mA; RS232 keypad	Dimensions Weight	60 x 60 x 97 mm 500 g
Pressure regulator Series SPRR 700 Page 53	Regulating range Flow rate Input signal	0-10 bar 1,000 l/min. 0-5 V; 0-10 V; 4-20 mA; RS232 keypad	Dimensions Weight	60 x 60 x 131 mm 450 g
Pressure regulator Series SPR 900 Page 53	Regulating range Flow rate Input signal	0-10 bar 4,000 l/min. 0-5V; 0-10V; 4-20mA; RS232 keypad	Dimensions Weight	62 x 62 x 158 mm 950 g
Pressure regulator Series SPR 1000 Page 53	Regulating range Flow rate Input signal	0-7 / 0-12 / 8-14 bar 5,000 l/min. 0-5 V; 0-10 V; 4-20 mA; RS232 keypad	Dimensions Weight	70 x 100 x 256 mm 1,300 g

SPECIAL SOLUTIONS







PRODUCT DESCRIPTION

MATRIX valves have a unique and innovative technology. The switching operation takes place without friction and with very low masses (Fig.1). This technique enables a service life of **up to 4 billion (!)** switching operations and consequently reduces the maintenance intervals and operating costs of a plant enormously. The very high repeat accuracy over the entire service life and the reliability ensure constant quality and productivity. The frictionless mechanism enables extremely fast switching times of < 1 ms for the complete switching operation (!) as well as a frequency of up to 1,500 Hz.

The modular design of the multi-valves (Fig. 2) enables the arrangement of multiple valves in a very tight space. Consequently up to 9 valves are arranged in one valve block of just $46 \times 46 \times 42$ mm. This constellation saves the piping of the individual valves, which in turn saves material, installation space and working time and therefore simplifies the entire pneumatic system.

In summary, the MATRIX valve technology enables completely new methods and approaches in pneumatics.

MATRIX valves are insensitive to vibration and acceleration.



Typical features of the MATRIX valves

To simplify the decision for a MATRIX valve, one can check the following basic requirements, which speak in particular in favour of this valve technique:

- reliability and long service life (> 500 millions cycles)
- · very good reproducibility over the entire service life
- · fast switching times
- high frequencies
- frequency control (PWM PFM)
- · proportional flow rate

- · compact design
- · low weight
- multifunctionality (multiple functions per valve unit)

Fig. 2

· customer-specific adaptations

Typical fields of application

- Medical technology & biotechnology
- Handling & robotics
- Regulation of vacuum
- Packaging industry
- Marking systems

- Sorting & recycling (up to 1,500 Hz)
- Regulation of pneumatic drives
- Proportional regulation of flow rates
- Textile industry
- Plant engineering





TECHNICAL INFORMATION

The valves can be controlled directly (ON/OFF) and with the following modulation:

- PWM / Pulse-Width-Modulation (Fig. 3)
- PFM / Pulse-Frequency-Modulation (Fig. 4)
- PNM / Pulse-Number-Modulation (Fig. 5)
- PCM / Pulse-Code-Modulation (Fig. 6)

A combination of modulations is also possible. This enables a wide range of the layout in the respective applications. A linear and/or proportional flow control is also possible. In the example of the 860 series valve, with the PCM control 256 flow rate levels can be called or set within 1 ms.



The Speed-Up technology of MATRIX requires 100% output from the control system merely in the opening phase and this is then reduced to a holding level after < 5 ms (Fig. 7). This saves > 90% of the energy costs and at the same time reduces the development of heat.



Medium

Compressed air quality of class 3 according to DIN ISO 8573-1 is required for fault-free functionality. The minimum requirement for our MATRIX valves are the classes 3/4/5 (see table).

	Oil content	Part	icles	Water	content
Class	mg/m³	Mm	mg/m³	DTP	g/m³
1	0.01	0.1	0.1	-70	0.003
2	0.1	1	1	-40	0.12
3	1	5	5	-20	0.88
4	5	15	8	3	6
5	25	40	10	7	7.8
6				10	94

Specification of the air quality when using the MATRIX valve series. Special valves and/or special applications may vary.

Current curve

Media compatibility of the MATRIX valves and pressure

Medium: Filter mesh size:

Ambient temperature:

regulators

Dry, non-lubricated air and neutral gases min. 40 microns (µ) -10° to + 50 °C Sealing materials and temperature range NBR: -10° to + 50 °C (standard) HNBR: -10° to + 80 °C (option, not for all series) FKM: -10° to + 80 °C (option, not for all series) With the optional sealing materials only the rocker seals are affected."

All flow rate values of the valves refer to 6 bar relative overpressure and unresisted flow.





320 SERIES | MICRO VALVE

Greatest efficiency in the smallest design – this describes the 320 series valve in just a few words.

The current trend is towards a drastic reduction of the dimensions, the weight and the energy requirement with increasing performance and service life at the same time.

The unique mechanism of the MATRIX valves enables maximum performances among the micro pneumatic valves. The valve has a power consumption of just 0.05 A. Once again it is evident, what efficiency this valve technology achieves.

The very small size of 8 x 23 x 28 mm combines a 2/2 and 3/2 function in NC or NO and can be used as individual or manifold mounted valve. Consequently the 320 series valve can be used for multiple functions.



Despite the narrow structural width a flow rate of 30 l/min. is achieved. In addition to this is the low weight of 9g, which represents an enormous advantage in applications with high acceleration and movement.

The low power consumption saves operating costs and permits smaller controls. Versatile functions enable an optimised inventory, the low mass preserves resources and the limited thermal radiation saves constructive interventions. A further aspect is the extremely long service life, which reduces the LCC costs (Life Cycle Costs) to a minimum.

Technical data

Switching time opening*	6/12/24 V: <3 ms	KK: <1.5 ms	
Switching time closing*	6/12/24 V: <1.5 ms	KK: <1.5 ms	
Maximum frequency	200 Hz	300 Hz	
Weight	9 g		
Protection class	IP52		

Outlets	1	
Flow rate	30 l/min.	
Function	2/2 and 3/2 way in NC or NO	
Pressure range	0-8 bar or vacuum	

*Varies with the working pressure

Possible functions



Possible controls

Direct / PWM / PFM Information see page 5



Section: Type 3/2 NC





MICRO VALVE | 320 SERIES

Ordering code



(1) without thread and plug-in connections

(2) according to the manifold the valve can also be used as 2/2 way
 (3) requires a Speed-Up! Control (see intro pages)





320 SERIES | MICRO VALVE

Drawings and connections



Accessories

Single manifolds for 2/2 function			
Connection Article code			
Push-in fitting	021.284Q		

Single manifolds for 3/2 function

Connection	Article code
Push-in fitting	021.244C
Bushing	021.333N
Bushing with assembly plate	021.350E

Multiple manifolds for 2/2 function

Number of	Article code	Dimensions		
seats	Article code	Y	Z	
For 2 valves	021.353H	31 mm	21 mm	
For 4 valves	021.354I	49 mm	39 mm	
For 6 valves	021.355J	67 mm	57 mm	
For 8 valves	021.357L	85 mm	75 mm	
For 10 valves	021.288U	103 mm	93 mm	

Multiple manifolds for 3/2 function

Number of	Article code	Dimensions		
seats	Article code	Y	Z	
For 2 valves	021.352G	31 mm	21 mm	
For 4 valves	021.265X	49 mm	39 mm	
For 6 valves	021.266Y	67 mm	57 mm	
For 8 valves	021.356K	85 mm	75 mm	
For 10 valves	021.267Z	103 mm	93 mm	
For 16 valves	021.274G	157 mm	147 mm	
For 32 valves	021.299F	331 mm	321 mm	

Note: All manifolds include mounting screws for the valves and screw connections.













MICRO VALVE | 320 SERIES

Valve cable AWG 28 / IP52

Longth	
Length	with cap
500 mm	021.260S
2000 mm	021.228M
5000 mm	021.484I



Product examples and special solutions







580 SERIES | MULTI-VALVE

With MATRIX, multi-valves, in other words a combination of multiple valves in one main body, are normally arranged in a circle. With the 580 series one has implemented a further concept, in order to enable a linear arrangement.

The 580 series valve combines 8 individual valves, whose outlets can be fitted with screw connections or a nozzle attachment. Mounting on a manifold is also possible.

Designed for a high flow rate, this valve is only available in the Speed-Up version.



Technical data

Switching time opening*	KK: <2 ms
Switching time closing*	KK: <2 ms
Maximum frequency	200 Hz
Weight	400 g
Protection class	IP62

*Varies with the working pressure

Outlets8Flow rate8x 135 l/min.Function2/2 way in NCPressure range0-5 bar

Possible function



Possible controls

Direct / PWM / PFM / PNM / Combination Information, see Page 5





Section: Type 2/2 NC



MULTI-VALVE | 580 SERIES

Ordering code



without thread and plug-in connections
 Requires a Speed-Up! Control (see intro pages)





580 SERIES | MULTI-VALVE

Drawings and connections



Standard version













12





G1/8







MULTI-VALVE | 580 SERIES

Product examples and special solutions







720 SERIES | INDIVIDUAL VALVE

The 720 series as individual or manifold mounting valve is available in a variety of variants. Whether for use with overpressure or vacuum, in 2/2 or 3/2 function, in NC or NO design, as individual valve or for mounting on a manifold, this valve can be configured accordingly.

Manifolds with 4 or 8 seats are available as accessories (other versions on request). A combination of NC and NO versions enables among other things a 5/2 function.



Technical data

Switching time opening*	12/24: <7 ms	JJ: <5 ms	KK: <2 ms	
Switching time closing*	12/24: <3 ms	JJ: <2 ms	KK: <2 ms	
Maximum frequency	100 Hz	140 Hz	250 Hz	
Weight		35 g		
Protection class		IP62		
*Varies with the working pressure				

Outlets	1
Flow rate	up to 100 l/min.
Function	2/2 or 3/2 way in NC or NO
Pressure range	between 0-8 bar or vacuum

valies with the working pressu

Possible functions



Possible controls

Direct / PWM / PFM Information, see Page 5





Section: Type 3/2 NC



INDIVIDUAL VALVE | 720 SERIES

Ordering code







720 SERIES | INDIVIDUAL VALVE

Drawings and connections



Standard version

















INDIVIDUAL VALVE | 720 SERIES

Accessories

Number of	Article code	Dimer	nsions
seats	Article code	Y	Z
For 2 valves	861.332E	45 mm	35 mm
For 4 valves	861.3101	70 mm	60 mm
For 8 valves	861.321T	120 mm	110 mm

Manifolds for 2/2 & 3/2 function

Manifold for 5/2 function

Number of	Article code	Dimer	isions
seats	seats Article code	Y	Z
For 2 valves*	861.919T	27.5 mm	54 mm

* Combination of one valve each in NC/NO for 5/2 function.

Note: All manifolds include mounting screws for the valves and screw connections.



Product examples and special solutions







750 SERIES | MULTI-VALVE

The 750 series combines 8 valves in one basic body and can be applied as multivalve in a wide variety of functions. Whether with overpressure or vacuum, in 2/2, 3/2, 3/3 or 5/2 function, in NC or NO version, as single module or for the multiple mounting on a manifold, this valve series can be configured accordingly.

A further feature is the possibility to supply the valve with two different pressures or to combine pressure and vacuum. Among other things this enables Pick-and-Place applications with only one multi-valve.

Manifolds with 2 to 8 seats are available as accessories. The combination of different way functions in NC or NO, pressure and vacuum as well as different flow capacity is possible.



Technical data

Switching time opening*	12/24: <7 ms	JJ: <5 ms	KK: <2 ms
Switching time closing*	12/24: <3 ms	JJ: <2 ms	KK: <2 ms
Maximum frequency	100 Hz	140 Hz	250 Hz
Weight	751 : 38	30 g / 752: 330 g / 754: 340 g / 7	58: 350 g
Protection class		IP52 – IP62 – IP65	
* Varies with the working pressure			

Outlets	1, 2, 4 or 8
Flow rate	up to 700 l/min.
Function	2/2 or 3/2 way in NC or NO
Pressure range	between 0-8 bar or vacuum

Possible functions



Possible controls

Direct / PWM / PFM / PNM / Combination Information, see Page 5



Section: Type 3/2 NC





Ordering code



- (1) Only available in the operating voltage JJ or KK
- (2) Integrated diodes only for version 754/758 with 4/8 signals
- (3) Easy Plug System see accessories. Not available for valves with 1 or 2 signal cables.
- (4) Including Easy Connection
- (5) Only available in the operating voltage KK
- (6) 100% ED only with power reduction
- (7) Requires a Speed-Up! Control (see intro pages)





750 SERIES | MULTI-VALVE 2/2 AND 3/2 FUNCTION

Drawings and connections

Type 751









Type 752













MULTI-VALVE 2/2 AND 3/2 FUNCTION | 750 SERIES

Drawings and connections









Type 758













750 SERIES | MULTI-VALVE 5/2 FUNCTION

Ordering code



(1) Only available in the operating voltage JJ or KK

- (2) 4x NC and 4x NO in combination (= 4x 5/2 way, monostable) (3) 4 signals, of which 1 signal each for 2 outlets
- (5) Including Easy Connection
- (6) Only available in the operating voltage KK
- 100% ED only with power reduction (7)
- (8) Requires a Speed-Up! Control
- (see intro pages)

6 22



Technical data

Switching time opening*	12/24: <5 ms	JJ: <5 ms	KK: <2 ms	
Switching time closing*	12/24: <3 ms	JJ: <3 ms	KK: <2 ms	
Maximum frequency	100 Hz	100 Hz	150 Hz	
Weight	380 g			
Protection class	IP52 – IP65			

			-
Varies with the	working	pressure	

Outlets	8
Flow rate	up to 100 l/min.
Function	5/2 way, monostable
Pressure range	between 0-8 bar

Drawings and connections

Туре 758 5/2













750 SERIES | MULTI-VALVE DOUBLE SUPPLY IN 2/2 FUNCTION

Ordering code



(1) Only available in the operating voltage JJ or $\mathsf{K}\mathsf{K}$

- (2) Easy Connector System see accessories
- (3) Including Easy Connection

- (4) Combination of pressure/vacuum possible (e.g. for Pick-and-Place)
 (5) 100% ED only with power reduction
- (6) Requires a Speed-Up! Control (see intro pages)
- 24 BIBUS SUPPORTING YOUR SUCCESS



MULTI-VALVE DOUBLE SUPPLY IN 2/2 FUNCTION | 750 SERIES

Technical data

Switching time opening*	12/24: <7 ms	JJ: <5 ms	KK: <2 ms	
Switching time closing*	12/24: <3 ms	JJ: <2 ms	KK: <2 ms	
Maximum frequency	100 Hz	140 Hz	250 Hz	
Weight	350 g			
Protection class	IP52 – IP65			

Varies	with	the	working	nressure
vanes	WILLI	uie	working	pressure

Outlets	8
Flow rate	up to 100 l/min.
Function	2/2 way
Pressure range	between 0-8 bar

Drawings and connections

Type 758 DS 2/2















750 SERIES | MULTI-VALVE

Accessories

Number of costs	Article code	Dimensions		
Number of seats	Article code	Y	Z	
For 2 multi-valves	868.950E	140 mm	130 mm	
For 3 multi-valves	868.951F	195 mm	65 mm	
For 4 multi-valves	868.952G	260 mm	130 mm	
For 5 multi-valves	868.953H	325 mm	195 mm	
For 6 multi-valves	868.954I	390 mm	260 mm	
For 7 multi-valves	868.955J	455 mm	325 mm	
For 8 multi-valves	868.956K	520 mm	390 mm	

Manifolds for 2/2 & 3/2 function









Note: All manifolds include mounting screws for the valves and screw connections.

Mounting bracket 90°

For valve version	Article code
With integrated cable	868.466O
With Easy Connection	869.314E

Note: Mounting bracket includes mounting screws for the valve.



IP52 Valve cable AWG 24

	Article code		
Length	Controls		
	2	4	8
500 mm	868.870C	868.871D	868.872E
1,000 mm	868.873F	868.875H	868.877J
2,000 mm	868.874G	868.876I	868.878K
3,000 mm	868.845D	868.880M	868.881N







IP65 PVC valve cable AWG 24

	Article code		
Length	Controls		
	4	8	
1,000 mm	868.851J 868.850I		
2,000 mm	868.854M 868.852K		
3,000 mm	868.855N	868.853L	

IP65 PUR valve cable AWG 24

	Article code		
Length	Controls		
	4	8	
2,000 mm	868.883P 868.885R		
4,000 mm	868.884Q	868.886S	
5,000 mm	869.892K	869.865J	





Valve cable with optional D-Sub 15 PIN connector

IP52 valve cable plus D-Sub 15 PIN connector

	Article code		
Length	Controls		
	4	8	
500 mm	868.871D.15	868.872E.15	
1,000 mm	868.875H.15	868.877J.15	
2,000 mm	868.8761.15	868.878K.15	
3,000 mm	868.880M.15	868.881N.15	

IP65 PVC valve cable plus D-Sub 15 PIN connector

	Article code		
Length	Controls		
	4	8	
1,000 mm	868.851J.15 868.850I.15		
2,000 mm	868.854M.15	868.852K.15	
3,000 mm	868.855N.15	868.853L.15	

IP65 PUR valve cable plus D-Sub 15 PIN connector

	Article code		
Length	Controls		
	4	8	
2,000 mm	868.883P.15	868.885R.15	
4,000 mm	868.884Q.15	868.886S.15	
5,000 mm	869.892K.15	869.865J.15	





Illustration shows IP65 cable





750 SERIES | MULTI-VALVE

The class of protection specifies the suitability of electrical equipment for various ambient conditions. With regard to their suitability, the protected systems are classified in corresponding protection classes, so-called IP-Codes. The letters IP in the protection class designation are appended with two indicators. These indicate what scope of protection a housing provides against foreign matter and moisture.

IP52

- 5: Protected against dust in harmful quantity, complete protection against contact.
- 2: Protection against falling drops of water, when the housing is inclined up to 15°.

IP65

- 6: Dust-tight, complete protection against contact.
- 5: Protection against water jet (nozzle) from any angle.

More precise explanations can be found in the respective standards.

Easy Connector System for 750 series MATRIX valves







MULTI-VALVE – SPECIAL SOLUTIONS | 750 SERIES

Product examples and special solutions







820 SERIES | INDIVIDUAL VALVE

The 820 series is a valve with 2/2 function in NC (normally closed). A combination of two of these valves produces a 3/3 function in NC/NC. The 820 series was designed especially to create a compact 2/2 valve with high performance. Switching times of < 1 ms for the complete opening or closing phase, a flow capacity of up to 220 l/min. and a frequency of max. 500 Hz are configurable depending on the version. This high performance and dynamic is achieved through the unique and patented MATRIX technology and enables an outstanding repeat accuracy.



The features of this valve series are particularly suitable in applications which demand a high standard of reliability, constant process quality or also if no readjustment is desired in plants. The 820 series is available as individual valve as well as manifold mounting valve. Manifolds with 4 or 8 seats are available as accessories (other versions on request).

Technical data

Switching time opening*	24: <5 ms	KK: <1 ms	XX KK: <2 ms
Switching time closing*	24: <2 ms	KK: <1 ms	XX KK: <2 ms
Maximum frequency	140 Hz	500 Hz	50 Hz
Weight	25 g		
Protection class	IP62		

*Varies with the working pressure

Outlets	1
Flow rate	up to 220 I/min.
Function	2/2 way in NC
Pressure range	between 0-8 bar

Possible functions



*Technical data on request.

Possible controls

Direct / PWM / PFM Information, see Page 5



Section: Type 2/2 NC





INDIVIDUAL VALVE | 820 SERIES

Ordering code



(3)

Requires a Speed-Up! Control (see intro pages) (5)





820 SERIES | INDIVIDUAL VALVE

Drawings and connections

Manifold mounting version



Standard version















INDIVIDUAL VALVE - SPECIAL SOLUTIONS | 820 SERIES

Product examples and special solutions





820 ISD SERIES | INDIVIDUAL VALVE

The 820 ISD series (ISD = Integrated Speed-Up Driver) is an addition to the 820 series. In addition this series has a miniature controller, which is integrated directly on the valve. In this version the Speed-Up technology is the standard for high performance. For this the integrated miniature controller takes over the control of the Speed-Up switching.

As a result the valve can be operated with a standard 24 V signal without separate requirements or adaptations to existing controllers. With a switching time of < 2 ms for the complete opening or closing phase, a frequency of max. 300 Hz can be achieved with a max. flow capacity of 180 l/min.



The 820 ISD series can be used for the direct mounting on a manifold or in combination with a mounting flange also equipped with push-in fittings.

Technical data

Switching time opening*	YY: <2 ms WW: <2 ms		
Switching time closing*	YY: <2 ms	WW: <2 ms	
Maximum frequency	300 Hz 250 Hz		
Weight	25 g		
Protection class	IP67 IP62		

Outlets	1
Flow rate	up to 170 l/min.
Function	2/2 way in NC
Pressure range	between 0-8 bar

*Varies with the working pressure

Possible function



Possible control

Direct / PWM / PFM Information, see Page 5





Section: Type 2/2 NC



INDIVIDUAL VALVE | 820 ISD SERIES

Ordering code



(1) without thread and plug-in connections

(2) 1x 24 VDC supply voltage & 1x 5-24 V switching signal (e.g. PLC)





820 ISD SERIES | INDIVIDUAL VALVE

Drawings and connections

Manifold mounting version



Standard version

















INDIVIDUAL VALVE | 820 SERIES

Accessories

Manifolds for 2/2

Number of	Article code	Dimer	nsions
seats	Article code	Y	Z
For 4 valves	820.041B	70 mm	60 mm
For 8 valves	820.042C	120 mm	110 mm

Note: All manifolds include mounting screws for the valves and screw connections.



Product examples and special solutions







860 SERIES | MULTI-VALVE - PROPORTIONAL

With the 860 valve series MATRIX offers an unprecedented simple, compact and precise Digital Flow Control valve.

In a compact valve body of just 55 x 55 x 52 mm, 9 valves with 2/2 function in NC (normally closed) are combined on one pneumatic inlet/outlet. Each valve has a different nominal diameter and can be switched independently. This enables a proportional and/or linear flow rate.

Two configurations are available for a 6-Bit (64 levels) or 8-Bit (256 levels) control. Consequently, with the PCM technology up to 256 different, unambiguously defined as well as reproducible flow rate values can be set. The switchover



between the respective levels takes place within a millisecond. This extraordinary performance is achieved through the unique and patented valve technique of MATRIX. With the MATRIX PCM control card the valve can be controlled by means of an input signal of 0-10 V, which is subsequently converted to binary codes.

Technical data

Switching time opening*	<1 ms	
Switching time closing*	<1 ms	Outlets
Maximum frequency	500 Hz	Flow rate
Weight	450 g	Function
Protection class	IP52	Pressure range

Outlets	1
Flow rate	up to 750 l/min.
Function	2/2 way in NC
Pressure range	between 0-6 bar

*Varies with the working pressure

Possible function



Possible controls

Direct / PWM / PFM / PNM / PCM / Combination Information, see Page 5



Section: Type 2/2 NC



MULTI-VALVE – PROPORTIONAL | 860 SERIES

Variable flow rate with 6-Bit (64 levels) or 8-Bit (256 levels) resolution.

Type PX with 6-Bit resolution

Flow rate: min. 1.7 l/min. @ 1 bar max. 750 l/min. @ 6 bar



Characteristic of the flow rate when varying N (64 levels)

Type QX with 8-Bit resolution

Flow rate: min. 0.3 l/min. @ 1 bar max. 500 l/min. @ 6 bar



Characteristic of the flow rate when varying N (256 levels)

Extremely fast change of the flow rate level with very precise reproducibility

The performance of the MATRIX valves enables each of the 64 or 256 flow rate levels to be set within 2 milliseconds. Among other things, in process applications that enables a variety of individual process settings/changes during or in between the processes and consequently higher productivity as well as constant quality due to the reproducibility.



Example of the adjustment time between the flow rate levels (Fig. The 6-Bit Version)



Series 861 PCM with variable flow rate • 2/2





860 SERIES | MULTI-VALVE – PROPORTIONAL

Ordering code



(1) Among other things the flow rate value is dependent on the supply pressure

(1) The maximum flow rate refers to 6 bar rel. and c
(3) Customer-specific flow rates on request
(4) Requires a Speed-Up! Control (see intro pages) The maximum flow rate refers to 6 bar rel. and completely open valve





MULTI-VALVE - PROPORTIONAL | 860 SERIES

Drawings and connections

Туре 861





Customer Solutions







880 SERIES | MULTI-VALVE 2/2 • NC

The 880 series is a multi-valve with 2/2 function in NC (normally closed). Two integrated valve rockers in one compact body, combined with the Speed-Up control technique, enable a high flow capacity of 300 l/min., switching times from < 2 ms and a frequency of up to 450 Hz.

Optionally there is a miniature controller, which is integrated directly on the valve. In this version the Speed-Up technology can be operated with a standard 24 V signal without separate requirements or adaptations to existing controllers.

Depending on the version, the two integrated valve rockers can be switched together or separately, in order to switch 50% or 100% of the flow capacity. The 880 series is available as individual valve as well as manifold mounting valve.



Technical data

	KK	XX	ww
Switching time opening*		<2 ms	- -
Switching time closing*		<2 ms	
Maximum frequency	350 Hz	450 Hz	350 Hz
Weight		from 80 g	
Protection class	lass IP62 – IP65		
*Varies with the working pressure			
Quittata		4	

Outlets	1
Flow rate	430 l/min.
Function	2/2 way in NC
Pressure range	between 0-8 bar

Possible function





Direct / PWM / PFM / PNM / Combination Information, see Page 5



Section: Type 2/2 NC





MULTI-VALVE 2/2 • NC | 880 SERIES

Ordering code



(1) without thread and plug-in connections

(2) Enables switching of 50% or 100% of the flow capacity

(3) Only available with WW or XX voltage

(4)

Requires a Speed-Up! Control (see intro pages) 1x 24 VDC supply voltage & 1x 5-24 V switching signal (e.g. PLC) (5)





880 SERIES | MULTI-VALVE 2/2 • NC

Drawings and connections





Standard version





문









Product examples and special solutions







890 SERIES | MULTI-VALVE

The 890 series is a multi-valve and contains 9 individual valves with 2/2 function in NC (normally closed). Depending on the configuration one achieves a flow capacity of max. 1,530 l/min. and has up to 9 valve outlets which can be switched individually. Due to the modular design, this valve series is also excellently suited as base valve for a wide variety of output requirements. 6 different versions can be created with a mounting kit. This is done by simply changing the outlet flanges and can be carried out by the user. This simplifies e.g. the storage, increases the availability and saves costs.



The body has the dimensions of just 46 x 46 x 41.5 mm and has a central air supply. Due to the possibility of a step switch, one can vary the flow rate proportionally and consequently also save enormous energy costs depending on the application.

The Speed-Up version enables a switching time of < 1 ms and a frequency of 500 Hz, which, among other things, effects an extremely high repeat accuracy.

Technical data

Switching time opening*	24: <5 ms	KK: <1 ms	
Switching time closing*	24: <2 ms	KK: <1 ms	
Maximum frequency	140 Hz	500 Hz	
Weight	210 g to 320 g		
Protection class	IP62		

Outlets	1, 2, 3, 4 or 9
Flow rate	up to 1,530 l/min.
Function	2/2 way in NC
Pressure range	between 0-8 bar

*Varies with the working pressure

Possible function



Possible controls





Section: Type 2/2 NC



MULTI-VALVE | 890 SERIES

Ordering code



Only available in the operating voltage KK
 Outlet flange without thread and plug-in connections

 (3) In the standard every outlet has a signal cable. Optionally one can:
 apply 9 signals to one outlet, to achieve a proportional flow rate (e.g. 891.9 = 1 outlet, 9 signals)

• switch up to 9 outlets at the same time with one signal (e.g. 899.1 = 9 outlets, 1 signal). Only for version MX or NX.

- (4) Only available with
- 9 signals (5) Requires a Speed-Up!
- Control (see intro pages)





890 SERIES | MULTI-VALVE

Drawings and connections

Manifold mounting version



Manifold mounting version with flange



















MULTI-VALVE | 890 SERIES

Drawings and connections







890 SERIES | MULTI-VALVE

Drawings and connections

Туре 894



Туре 899



















MULTI-VALVE - SPECIAL SOLUTIONS | 890 SERIES

Product examples and special solutions







EPR / SPR SERIES | PRESSURE REGULATOR

Overview MATRIX Pressure Regulators

The EPR and SPR series are compact electronic pressure regulators for the pneumatics with an 8 Bit microprocessor. The control signal can be in the form of voltage or current, per direct input on the keypad of the unit as well as via RS-232.

The MATRIX pressure regulators are available in two basic versions:

Type **A** Control via voltage signal (V), current signal (mA) or via RS-232

Type **D** Control via voltage signal (V), current signal (mA), via RS-232 or keypad on the unit including digital display

Depending on the version, D-Sub 15, M12 or DIN 43651 are available as interfaces.

MATRIX Pressure Regulator EPR100 Series

- Regulating range 0-7 bar
- Flow rate 80 l/min.
- Input signal 0-5 V; 0-10 V; 4-20 mA; RS232
- Interface D-Sub 15
- Optionally with keypad on the unit
- Dimensions 118x70x40 mm
- Weight approx. 0.4 kg

MATRIX Pressure Regulator EPR 200 / 300 / 500 Series

- Regulating range 0-7 bar
- Flow rate max. 500 l/min.
- Input signal 0-5 V; 0-10 V; 4-20 mA; RS232
- Interface DIN 43651, ISO M12
- Optionally with keypad on the unit
- Dimensions 60x60x97 mm
- Weight approx. 0.5 kg











PRESSURE REGULATOR | EPR / SPR SERIES

MATRIX Pressure Regulator SPR 700 Series

- Regulating range 0-10 bar
- Flow rate 1,000 l/min.
- Input signal 0-5 V; 0-10 V; 4-20 mA; RS232
- Interface DIN 43651, ISO M12
- Optionally with keypad on the unit
- Dimensions 60 x 60 x 131 mm
- Weight approx. 0.45 kg

MATRIX Pressure Regulator SPR 900 Series

- Regulating range 0-10 bar
- Flow rate 4,000 l/min.
- Input signal 0-5 V; 0-10 V; 4-20 mA; RS232
- Interface DIN 43651, ISO M12
- Optionally with keypad on the unit
- \bullet Dimensions 62 x 62 x 158 mm
- Weight approx. 0.95 kg

MATRIX Pressure Regulator SPR 1000 Series

- Regulating range 0-7 / 0-12 / 8-14 bar
- Flow rate 5,000 l/min.
- Input signal 0-5 V; 0-10 V; 4-20 mA; RS232
- Interface D-Sub 15 or DIN 43651 socket
- · Optionally with keypad on the unit
- Dimensions 70 x 100 x 256 mm
- Weight approx. 1.3 kg

You can gladly receive more detailed information and documentation about the MATRIX pressure regulators on request.











SPECIAL SOLUTIONS

From the *Idea*



... to **Prototype**



From the **Conception**

... to Series

... to new *Markets*





From the **Development**









SPECIAL SOLUTIONS

Modular System

The modular expansion of all MATRIX valve series enables the perfect basis for application-specific adaptations.

- > Change of the position for the inlet/outlet connection
- > Specified flow rate values also for digital control (binary code)
- > Multiple supply of different pressures (e.g. pressure and vacuum)
- > Multiple supply of different media (e.g. doser/mixer of gases)
- > Customer-specific interfaces (mechanical and electrical)

Due to the design, customer solutions are also economically feasible in small batches.

890 Series

Versions



Basis valve 890

The basis of the 890 series is the manifold version with 9x 2/2 NC valves. In combination with the respective outlet flange, the outputs of the individual valves are cumulated. That produces different flow rate values, which, depending on the configuration, can also be regulated proportionally.



Types	891	892	893	894	899
MX	100 ÷ 900	100 ÷ 400	100 ÷ 300	100 ÷ 200	100
NX	140 ÷ 1,260	140 ÷ 560	140 ÷ 420	140 ÷ 280	140
OX	170 ÷ 1,530	170 ÷ 680	170 ÷ 510	170 ÷ 340	170

Flow rate values per outlet

This modular system also facilitates storage with higher availability at the same time as well as simplification of the plant control.

Custom production













CUSTOMER- AND BRANCH SOLUTIONS

Solutions for industry and automation



Combination for proportional flow rate



Combination and Sub-D interface



Valve manifold with central supply and nozzle attachment



Combination of multi- and individual valves

Expandable valve batteries



Multi-valve with customer-specific interface





Modular multi-valves with common supply- and support bar



VALVE MANIFOLDS

High-speed valves and nozzle bars for the sorting technology

The patented MATRIX valve technology enables extremely fast switching times, very high frequencies and, with the individual/multi-valve layout, a variety of individual installation arrangements.

Consequently, MATRIX offers a large range of Plug-and-Play products for air ejection systems with the following highlights:

- > Nozzle grids from 2 mm with individual and multifunctional configuration possibilities
- > Switching time of < 1 ms for the 100% opening or closing of the air duct
- > Valve configurations with > 4,000,000,000 switching operations and constant performance
- > Variable flow rate and configurations for maximum flexibility
- > Valve manifolds pre-assembled and 100% tested

Modular system for customer-specific sizes and configuration



_		E	
雦		D	
A	В		C A





VALVE MANIFOLDS

Model examples from sorting technology installations

GS Series

13

B

Compact multi-valves with directly mounted nozzle flange



GM Series



Nozzle bar configurable with individual and multi-valves



GMT Series

Twin nozzle bar configurable with individual and multi-valves





GMN Series

Combination of individual and multi-valves with nozzle bars







MEDICAL TECHNOLOGY

Valves for the medical technology

Respiratory & Bronchial

Regulation and dosing of neutral gases



Physiology

Regulation and dosing of neutral gases



Despite the 100% functional test of all MATRIX valves, the products for the medical technology are subjected to additional quality assurance up to and including complete traceability of all installed components. Furthermore, these products are manufactured and customer-specific tested, logged and packed in separate clean rooms.



This high quality assurance permits a Plug-and-Play component for the medical technology.

Note:

Ē

The custom solutions shown are merely an extract from our delivery program and possibilities. Please contact us and we will gladly check our possibilities for your requirements.





ENGINEERING LOGISTICS SERVICES



